



PHOTO CONTROLS LC2000

WITH TWIST LOCK MOUNTING

IMPORTANT OPERATING INSTRUCTIONS

RATING CHART



MODEL	NORMAL OPERATING VOLTAGE	BALLAST VA	TUNGSTEN WATTS
LC2000	110-277	1800	1000

MOUNTING Insert prongs of Photo Control into female socket and twist in clock-wise direction with slight pressure until unit is secure. "Eye" (window in plastic housing) should be oriented in a northerly direction, if possible, for best operating results, and should be positioned so as to be unaffected by the controlled light, auto headlights, window lights, signs, etc.

Wattage of controlled lights cannot exceed rated capacity of Photo Control.

NOTE: Mount unit so that top of case is in an upright position.

TESTING: Make sure circuit is clear of shorts before applying power. Cover "EYE" with hand to activate unit. Repeat several times. Under extremely bright light it may be necessary to place an opaque item over the entire unit to activate it. Slight buzz from unit does not impair operation.



Common problems - read first!

- 1. Do not face the photocell into the midday sun.** If installed on the south side of a building, face east or west or point the photo control down toward the ground. The best direction to face the photo control is north.
- 2. Do not face the photocell where it can see artificial light.** Light from windows, signs, street lights, etc., will cause the photo control not to switch on. The photo control should not be positioned so that it sees the light it is controlling (or reflected light). These conditions will cause the light to cycle on and off.
- 3. When you are testing the photo control, be sure to turn on the power (load will come on) and wait up to 5 minutes for photocell to switch load off.** For further testing cover the photo control completely with black tape or another dark material to simulate night conditions. If you can't cover the control with tape, try covering the photo control with the shipping carton to simulate night conditions.

Troubleshooting Chart

Problem	Cause	Solution
Fuse blows when power is connected.	Load exceeds fuse rating. Photo control is incorrectly wired. Short in wiring.	Reduce load to within fuse rating. Check wiring.
Load lamp blinks during the day, but is on at night.	Photo control is incorrectly wired.	Rewire as shown in wiring diagram.
Load lamp blinks at night, but is off during the day.	Too much light is striking photo eye. Light from load is shining or being reflected on eye of photo control. High pressure sodium lamp is at end of life.	Reorient or relocate photo control. Relocate or reorient light source. See high pressure sodium note below.
Load stays on.	Line voltage is exceptionally low. Photo control is not rated at voltage being used. Contacts are welded due to excessive load. Not enough light strikes photo control eye.	Have power company check voltage at control. Replace control with unit of correct voltage Replace control and connect only rated load. Reorient or relocate photo control.
Load stays off.	Lamp and/or ballast is burned out. Line voltage is exceptionally high. Photo control is not rated at voltage being used. Too much light strikes eye of photo control at night.	Replace lamp and/or ballast Have power company check voltage at control. Replace control with unit of correct voltage. Reorient or relocate photo control.
Photo control operates normally for a short time, then remains on.	Contacts are welded due to excessive load.	Replace photo control and connect only rated load or smaller.
Photo control fails to switch off and photo-cell shows evidence of burning or arcing across serpentine pattern.	Photo control damaged by lightning or other high-energy transient.	Replace photo control. Consider installing "LA" Model Control, lightning arrestor or surge protection device in circuit.
High pressure sodium or mercury vapor end-of-life failure.	With these lamps the end-of-life failure mode is one of cycling (the initial cycling period may be as long as one-hour but will shorten to as little as one minute).	Replace lamp and/or ballast.

IMPORTANT NOTE:

The load being controlled by your photo control will be on even if installation is done during daylight hours. Allow a few minutes for the photo control to operate and turn the load off. To test the control in daylight, cover the photo eye completely and wait for the load to switch on (up to five minutes may be needed). If this does not work, switch breaker off and wait ten minutes. Switch breaker on. The load should be on.

If within three (3) years from the date of purchase, this product fails due to a defect in material or workmanship, Intermatic Incorporated will repair or replace it, at its sole option, free of charge. This warranty is extended to the original household purchaser only and is not transferable. This warranty does not apply to: (a) damage to units caused by accident, dropping or abuse in handling, acts of God or any negligent use; (b) units which have been subject to unauthorized repair, opened, taken apart or otherwise modified; (c) units not used in accordance with instructions; (d) damages exceeding the cost of the product; (e) sealed lamps and/or lamp bulbs, LED's and batteries; (f) the finish on any portion of the product, such as surface and/or weathering, as this is considered normal wear and tear; (g) transit damage, initial installation costs, removal costs, or reinstallation costs.

INTERMATIC INCORPORATED WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS OR IMPLIED WARRANTIES. ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE HEREBY MODIFIED TO EXIST ONLY AS CONTAINED IN THIS LIMITED WARRANTY, AND SHALL BE OF THE SAME DURATION AS THE WARRANTY PERIOD STATED ABOVE. SOME STATES DO NOT ALLOW LIMITATIONS ON THE DURATION OF AN IMPLIED WARRANTY, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

This warranty service is available by either (a) returning the product to the dealer from whom the unit was purchased, or (b) mailing the product, along with proof of purchase, postage prepaid to the authorized service center listed below. This warranty is made by: Intermatic Incorporated/After Sales Service/7777 Winn Rd., Spring Grove, Illinois 60081-9698/815-675-7000 <http://www.intermatic.com> Please be sure to wrap the product securely to avoid shipping damage.

INTERMATIC INCORPORATED
SPRING GROVE, ILLINOIS 60081-9698