

Installation Instructions: 24C

- 1- Turn off power
- 2- Remove Kit from box and check parts list
- 3- Remove ballast/wireway cover from existing fixture
- 4- Remove lampholders and socket bars from existing housing
- 5- Remove ballast
- 6- Place 24C LED board and driver retrofit kit on existing housing
- 7- Attach existing black power line wire to black port in luminaire disconnect from driver
 - a. Must use 18-22 AWG Solid Wire or 16-12 AWG stranded < 19 Strands per pole
- 8- Attach existing white power line wire to white port in luminaire disconnect from driver
 - a. Must use 18-22 AWG Solid Wire or 16-12 AWG stranded < 19 Strands per pole
- 9- Attach green ground wire to green ground screw on existing channel
- 10- Install supplied screw(s) in slot(s) on both ends and each side of new wireway cover into side of existing channel. For 8' channel also install screw(s) in center side slots
- 11- Turn on power

Wiring Diagram:

