
Installation Instructions for NTM-713, NTS-714, NTM-513

WARNING: FIRE/ELECTRICAL HAZARD

Installation of this trim must be made in accordance with the current edition of the National Electrical Code and all applicable state and local building codes. The final installation must be approved by the appropriate, qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing or maintaining this electrical system. Do not exceed limits as shown on the lamping label found on the outside surface of the trim.

INSTRUCTIONS:

1. Install gasket to top of baffle. (700 Series only)
2. Clip socket from fixture to top of baffle.
3. Secure baffle trim into housing by squeezing ends of torsion springs together, inserting them into brackets inside housing, then releasing.
4. Install light source into trim.

