

## TROUBLE SHOOTING TIPS

1. If entire tree does not light, make sure extension cord plug is securely inserted into a working electrical outlet.
2. If an entire section of the tree does not light, please check a) to be sure that all plugs within the tree are securely connected, b) fuse in the extension cord and replace if necessary.


**CAUTION! ALWAYS UNPLUG YOUR TREE FROM ITS POWER SOURCE BEFORE ATTEMPTING EITHER FUSE OR BULB REPLACEMENT**

## FUSE REPLACEMENT:

This product comes with overload protection (fuse). A blown fuse indicates an overload or short circuit. If a fuse blows, unplug tree from wall outlet.


Replace the fuse as:

1. Grasp plug and remove from its power source.
2. Locate blown fuse by sliding access cover on top of plug towards prongs.
3. Remove blown fuse by turning the plug over. Fuses should fall into your hand.
4. Insert new fuse. Close fuse cover by sliding fuse access cover towards the cord.



## BULB REPLACEMENT

1. Grasp plug and remove it from the receptacle or other outlet device. NEVER unplug by pulling on cord.
2. Pull the lamp and plastic base straight out of the lampholder.
3. Replace the lamp with only 2.5 volt spare bulb - provided in the carton.



## BASIC PRECAUTIONS WHEN USING THE PRODUCT:

1. This is an electrical product - NOT A TOY! To avoid risk of fire, burns, personal injury and electrical shock it should not be played with.
2. Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
3. Do not cover product with cloth, paper or any material when product is in use.
4. Do not hang ornaments or other objects from cord, wire, or light string. Hang ornaments only on the tree itself.
5. For your safety, unplug the product when leaving the house, retiring for the night, or if left unattended.
6. Do not let bulbs rest on the supply cord or any wire.
7. Do not close doors or windows on the product or extension cords as this may damage the wire insulation.

## STORAGE TIPS

1. Unplug extension cord from the wall outlet, and unplug each section of extension cord.
2. Pressing branches against stem before removing the top to bottom sections gently. Lastly, remove the bottom section from metal tree stand.
3. Carefully replace the tree in its box and tape it shut. Store carton in a cool, dry place, Do not store the tree in a damp area or in an area where the temperature exceeds 100°F.