


Assembly instruction STYLE: 23049

Parts list

A	Chair Top	1pc
В	Front Leg	2pcs
С	Back Leg	2pcs
D	Flat Washer	8pcs
Е	Spring Washer	8pcs
F	Bolt	8pcs
G	Allen WRENCH	1PC





- 1.Lay the chair top (A) on a solid non-abrasive surface such as carpet or cloth as shown below.
- 2.Attach each leg (B/C) to the seat frame of chair top (A) as shown, using flat washers (D), spring washers (E) and bolts (F). Securely tighten all bolts by Allen wrench (G), but do not over tighten the bolts.
- 3.Please cover(H) fabric.
- 4. Assembly is now complete.

PO BOX 55B/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151 www.uttermost.com