
AD1

AD1

INVERTER - INTERRUPTIBLE



- 1 AC INPUT SELECT PROPER VOLTAGE LEAD AND CAP UNUSED LEAD.
- ② GROUND WIRE CONNECT FIXTURE SUPPLY GROUND AND UNIT GROUND IN ACCORDANCE WITH LOCAL AND NATIONAL CODES.
- (3) IF USING A SECONDARY AC INPUT, SELECT PROPER VOLTAGE LEAD AND CAP UNUSED LEAD.
- (4) USE A 277V RATED SWITCH IF CONNECTING TO 277V INPUT.
- (5) FLYING LEADS SELECT PROPER VOLTAGE LEAD AND CAP UNUSED LEAD.

IIS_125_375

