

## LED-SL42 LED WALL PACK RUBBER O-RINGS.

Use the O-Ring with the hole in the center  
To prevent flashing. Place the O-Ring over  
The red sensor lens located on the back of the  
LED Wall Pack. Use the O-Ring without a hole  
To cover the sensor for manual use with a switch.

