# **LED SHOEBOX FIXTURE**

24W / 48W / 100W / 150W / 200W / 300W

**INSTALL INSTRUCTIONS** 

## **SPECIFICATIONS**

| ITEM# | DESCRIPTION   | WATTS | COLOR | LUMENS | CRI | VOLT   | HOURS  |
|-------|---|-------|-------|--------|-----|--------|--------|
| 83505 | LED SHOE BOX FIXTURE 24W/50K/90-295V-4" SQ POLE/WALL MOUNT/BRONZE - SL® | 24    | 5000K | 2274   | 75  | 90-295 | 50,000 |
| 83509 | LED SHOE BOX FIXTURE 48W/50K/90-295V-4" SQ POLE/WALL MOUNT/BRONZE - SL® | 48    | 5000K | 5006   | 75  | 90-295 | 50,000 |
| 83512 | LED SHOE BOX FIXTURE 100W/50K/90-295V-4" SQ POLE/WALLMOUNT/BRONZE - SL® | 100   | 5000K | 9780   | 75  | 90-295 | 50,000 |
| 83517 | LED SHOE BOX FIXTURE 150W/50K/90-295V-4" SQ POLE/WALLMOUNT/BRONZE - SL® | 150   | 5000K | 14825  | 75  | 90-295 | 50,000 |
| 83520 | LED SHOE BOX FIXTURE 200W/50K/90-295V-4" SQ POLE/WALLMOUNT/BRONZE - SL® | 200   | 5000K | 20424  | 70  | 90-295 | 50,000 |
| 83522 | LED SHOE BOX FIXTURE 300W/50K/90-295V-4" SQ POLE/WALLMOUNT/BRONZE - SL® | 300   | 5000K | 29002  | 70  | 90-295 | 50,000 |

This fixture is suitable for wet locations, IP65.

Published lumens on LED products are approximate and may vary slightly.

#### WARNING

Installation, wiring or maintenance must be handled by professional technicians. Turn power off; to ensure reliable grounding and personal safety.

Do not cover any part of the fixture; this can cause overheating.

If wall mounting; the wall should be of sufficient strength to hold the fixture's weight.

Do not use in areas that are not properly ventilated from strong fumes.


# PLEASE FIND A QUALIFIED ELECTRICIAN FOR INSTALLATION



### **FIXED 4" SQUARE POLE MOUNT**

- 1. Connect lamp power input line with main power cord.
- 2. Attach mounting bracket to pole, tighten the screws, the installation is completed.





### ADJUSTABLE SLIP FITTER (Item#: 83530)

- 1. Lamp pole diameter should be less than connection tube diameter; loosen screws on connection tube.
- 2. Remove the 4" Square Pole Mount
- 3. Connect lamp power input line with main power cord.
- 4. Put lamp pole into connection tube, then tighten the screws, the installation is completed.
- 5. Lighting angle can be adjusted as required.





