

# Battery Operated Window Candle

## Assembly:

1. Unscrew bulb
2. Insert 4 x AA batteries (+ side up)
3. Replace bulb.
  - a. Candle will turn on once the bulb is fully screwed in.
  - b. Timer is set when candle is turned on. Candle will stay lit for 6 hours, turn off, and turn back on at the same time every day.
  - c. To reset daily timer, unscrew bulb and screw back in at desired start time.

**Height Adjustment:** Candle height has two positions.

## Shorter:

1. Remove rubber ring from bottom of candle



2. Slide candle through base



3. Replace rubber ring
4. Slide candle up into base to rubber ring is seated at the bottom of the base.



## Taller:

1. Remove rubber ring from bottom of candle
2. Remove candle from base
3. Replace rubber ring on bottom of candle
4. Place candle in top of base so rubber ring is seated in top of the base

