### LUNERA®

## LUNERA MH LED HORIZONTAL

145W-82W LED Replacement for Metal Halide Lamps
Type A - Ballast Driven


#### **Installation Description**

The **LUNERA MH LED HORIZONTAL** lamp is a multi-watt plug and play (Type A, ballast driven) LED replacement for horizontally oriented, Metal Halide (MH) lamps with a mogul (E39) base. It can be installed directly using the existing magnetic MH ballast.

# 400W/250W/ 175W Clear Lens

#### Installation Instructions - Ballast Driven (Type A)

- **1.** Power OFF the Metal Halide (MH) fixture. Let the existing MH bulb cool down before installing the LUNERA MH LED HORIZONTAL lamp.
- 2. Carefully remove the existing MH bulb. Unscrew the lamp from the base slowly to avoid breakage. Be sure to properly recycle the MH lamp.
- 3. Check the MH enclosure to ensure the LED lamp is compatible with the MH lamp being replaced. The LUNERA MH LED HORIZONTAL can replace a 400W, 250W, or 200W E39 Mogul MH lamp. If the MH LED model does not match the rated fixture wattage, stop. Do not install.
- 4. Install the LUNERA MH LED HORIZONTAL lamp into the existing E39/EX39 mogul base socket. If the lamp does not seat properly, do not apply force. Check to make sure the fixture has the E39/EX39 mogul required socket.
- 5. Turn ON power. If the MH LED lamp flickers, strobes, or fails on installation, immediately Turn OFF power. The MH LED lamp may not be compatible with the intended installation.





#### **Multi-watt Capability**


400W (M59) MH

250W (M58) MH

175W (M57) MH









#### **Intended Applications**

The LUNERA MH LED HORIZONTAL lamp is designed to replace Metal Halide (MH) lamps in the following compatible applications.

| Lamp Replaced                                   | Mount      | Fixtures   | Socket                                     |
|---|------------|--|--|
| 400W 250W 175W<br>M59 M58 M57                   | Horizontal | Shoebox / Wallpack with or without (sealed) lens | Horizontal Mount MH<br>E39/EX39 Mogul Base |
|   |            |  |  |
| Power Sources                                   |            | Controls   |  |
| MH CWA Ballasts Check for ballast compatiblity. |            | Rocker Switch<br>(non dimming)                   |  |
| CWA BALLAST                                     |            |  |  |

#### **Incompatible Applications**

Installation of the LUNERA MH LED HORIZONTAL lamp in INCOMPATIBLE MH applications may cause the lamp flicker, strobe, or fail entirely.

| Incompatible Power Sources                   |  | Incompatible Sockets      |                  |
|--|--|---------------------------|------------------|
| Direct Line Voltage (AC voltage - 120V/277V) | Ballasts not specified on Lunera's compatibility list. | High Pressure Sodium Lamp | Dimming Controls |
| Electronic Ballast                           | Connected to a LED driver                              | E26 Base<br>Socket        | Φ                |