

INSTALLATION GUIDE MODEL #: ET8-2141T-12 / ET8-2151T-12

Linear Series | T8 Class 4 ft. Bypass Ballast LED Tube



Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday

T8 Tube
Bypass Ballast


PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

WARNINGS CAUTIONS • Please read the installation instructions very carefully and follow the Check whether the system is an Electro Magnetic ballast based system wiring instructions to ensure safety or electronic ballast based system.and follow instructions accordingly. · Product is not dimmable When installing the LED tube, ensure the diffuser of the tube is pointing · Always switch off the power supply before commencing work in the direction where the light is required. • Only apply in dry indoor environments. Outdoor applications require a Incorrect installation or wiring may cause product failure, or other isproper IP rated fixture sues! • Do not change the structure or any components of the led tube to Please operate right installation steps! ensure safety. • LED Tube is designed to fit in standard IEC compliant G13 bi-pin lampholders. • LED Tube must be installed by a professional electrician in accordance with the relevant electrical codes. · Please keep this Quick installation Guide for future system maintenance. WHEN BYPASSING A BALLAST ALWAYS HAVE A QUALIFIED ELECTRICIAN DO YOUR ELECTRICAL WORK.

BYPASS BALLAST INSTALLATION INSTRUCTIONS

Single Ended Bypassing of Magnetic Ballast

- 1. Turn-off power before installation.
- 2. Remove the existing ballast
- 3. Remove existing starter (If present)
- 4. Rewiring of BALLAST diagram per tube. Repeat for multiple tubes.
- 5. Results of rewiring should appear as shown.
- 6. Replace fluorescent tube with LED Tube
- 7. Remove any pre-existing labels and replace them with the labels provided with this product. Turn on.





INSTALLATION GUIDE MODEL #: ET8-2141T-12 / ET8-2151T-12

Linear Series | T8 Class 4 ft. Bypass Ballast LED Tube



Questions?

For customer service please call us at 1-888-743-5766 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday




PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION


WHEN BYPASSING A BALLAST ALWAYS HAVE A QUALIFIED ELECTRICIAN DO YOUR ELECTRICAL WORK.


BYPASS BALLAST INSTALLATION INSTRUCTIONS


Single Ended Bypassing of Electronic Ballast


- 1. Turn-off power before installation.
- 2. Remove the existing ballast
- 3. Rewiring of BALLAST diagram per tube. Repeat for multiple tubes.
- 4. Results of rewiring should appear as shown.
- 5. Remove any pre-existing labels and replace them with the labels provided with this product. Turn on.
- 6. Replace fluorescent tube with LED Tube












WARNING!


USE LED LAMPS ONLY.
THIS LUMINAIRE HAS BEEN
MODIFIED TO USE LED LAMPS
AND CAN NO LONGER OPERATE
THE ORGINALLY INTENDED
FLUORESCENT LAMPS SAFELY.
FLUORESCENT LAMPS TO THIS FIXTURE.





New Built Luminaires


Wire according to the number of tubes per Luminaire


Number of Tube	Wire acording to diagram
1	С
2	D
3	C+D
4	D+D











© 2018. Euri Lighting \mid A Division of IRTRONIX Inc. All Rights Reserved