


# User Manual



PLS READ CAREFULLY BEFORE INSTALLATION AND PRESERVE IT WELL. REPLACE ANY CRACKED PROTECTIVE SHIELD. MUST BE INSTALLED AND ASSEMBLED BY A QUALIFIED ELECTRICIAN.

## Technical data:



Item #	Watts	L	W	H	LF
VTF2UZDA1**K	24	2.07	0.34	0.25	1.31
VTF4UZDA1**K	20	4.04	0.30	0.25	2.95
VTF4UZDA2**K	40	4.04	0.34	0.25	2.95
VTF8UZDA1**K	65	8.00	0.34	0.25	4.59

## Safety Instruction:

1. Electrical works have to be done by technical persons.
2. Disconnect the lamp from the power supply and let the lamp cool down before replacing the luminaire.
3. Please do not touch the LED lamp with your hand when or before using.
4. When the lamp cover is broken, please change it as soon as possible, Never use the lamp without lamp cover.
5. In case of damages, disconnect the lamp from the power supply. Do not try to repair the lamp on your own. Repair has to be done by technical persons or customer service.
6. Please don't look at the lighting directly.
7. Please use the H05RN-F 3G1mm<sup>2</sup> wire.
8. Please make sure the ground wire has been connected before turning on the switch.

## Installation Drawing:

