

SAFETY INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY AND SAVE THEM, AS YOU MAY NEED THEM AT A LATER DATE.

- Read all safety precautions and installation instructions carefully before installing or servicing this fixture. Failure to comply with these instructions could result in potentially fatal electric shock and/or property damage.
- 2. It is recommenede that a qualified electrician perform all wiring. This fixture must be wired in accordance with national and local electrical codes.
- 3. WARNING:Do not handle any energized fixture or attempt to energize any fixture with wet hands or while standing on a wet or damp surface or in water.
- 4. WARNING:To reduce the risk of electrical shock, and to assure proper operation, this fixture must be adequately ground-ed. To accomplish proper grounding, there must be a separate ground wire (green) contact between this fixture and the ground connection of your main power supply panel.
- 5. CAUTION: Make sure that the power source conforms to the requirements of the fixture (see labels on fixture housing). This fixture is designed for use in a 110-120VAC,60Hz.
- 6. CAUTION:Make sure power is off at fuse or circuit breaker box. Check wires for damage or scrapes. If power supply wires are within three inches of the LED driver power supply, use wire suitable for at least 90°C (194°F).
- 7. This fixture is intended to be used for general indoor lighting in dry or damp locations only.
- 8. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- 9. Any modifications to this fixture may void the warranty and interfere with the safe operation of the luminaire.

NEEDED TOOLS

- Flat Blade Screwdriver
- Phillips Screwdriver
- Drill

Drill Bits

Wire CutterWire Stripper

Pliers

Hammer











INSTRUCTIONS


Disconnect electrical power at fuse or circuit breaker box before installing or servicing any part of this fixture. Carefully remove the fixture from the carton, and check that all parts are included.

1. Carefully remove diffuser(A) by squeezing rounded back edge with forefingers while hoding front side with thumbs.



Note: Fixture is provided with knockouts for use with hardwire connector strain relief (included).





GlobaLux Lighting LLC – 2037 S. Vineyard Ave. Ontario, CA 91761 – 909-591-7605 Fax: 909-590-3220 www.globaluxlighting.com LED Undercabinet

- 3.Determine appropriate knockout for removal in relationship to incoming powr supply. To remove knockout, place standard screwdrive on edge of circle opposite retaining tab and gently strike with hammer untill it releases. Grip edge with pliers and fiex back and forth till knockout is removed.
- 4. If using hardwire connector (AA) assemble connector end cap to body using 2 mounting screws (BB). Leave screws loose to accommodate installation of power supply wires. Position hex nut inside channel over hole from knockout and thread connector assembly into nut until snug and screw heads are facing downward.
- 5. Position channel body (B) in desired mounting location and mark center point in small location of keyhole slot. Drill pilot hole at market locations. Screw in mounting screws (BB) leaving space for channel body. Slide channel (B) over mounting screws. Lift and shift channel into position and tighten screws.

WIRING

i bal

Note: all wiring must be made inside channel body and cover. **CAUTION:** Make sure power is off at fuse or circuit breaker box. Check wires for damage or scrapes. If power supply wires are within three inches of the LED driver power supply, use wire suitable for at least 90°C (194° F) $_{\circ}$

6. Insert power supply wires through hardwire connector and tight screws to secure. Strip 3/8" from black and white wire leads.

Use wire nuts (CC) to connect white wire to neutral supply wire, black wire to power supply wire and green to ground supply wire. Tuck all wire neatly under channel cover, Install channel cover (C) back onto channel (B) and secure by snapping under channel body tabs.

Re-install diffuser (A) onto channel body front lip and push to zip lock back flange onto channel cover.

Restore power at fuse or circuit breaker box.

7. Color (CCT) Option switch: To choose between 3000k (warm) and 4000K (Cool) light color, locate switch opposite On/Off power switch.

Select warm (WW) or cool (CW) from the markings on the switch and press to select.

Convenience Outlet: Rated for 120V, 15 AMP MAX

ASSEMBLY INSTRUCTIONS

THE LIGHT DOES NOT COME ON AT ALL:

- a) Make sure the wall switch and circuit breaker are on
- b) Make sure the wiring is correct
- 2. Fuse blows or circuit trips when light is turned on:
- a) Check for crossed wires, ensure wiring is correct

If unable to fix any of the above issues, please consult a certified electrician.

