


INSTALLATION INSTRUCTION

Dual Mode Internal Driver For Compatible Tube

Installation Guide:














2 Fluorescent


4 LED T8 InstantFit

5 LED T8 InstantFit

"Plug" and "Play" procedure


- 1. Turn off the power
- 2. Remove diffuser (if provided).
- 3. Remove the fluorescent tubes. Please dispose of these items properly as they contain mercury.
- 4. Put led tube in the lighting fixture.
- 5. Install the led tubes, close the diffuser (if provided).
- 6. Turn on the power.






Retrofit Procedure

- 1. Turn off the power
- 2. Remove diffuser (if provided).
- 3. Remove the fluorescent tubes. Please dispose of these items properly as they contain mercury.
- 4. Cut the wires as shown in the diagram.
- 5. Make the new wire connect to branch circuit as shown.
- 6. Replace the cover over the wiring chanel.
- 7. Install the led tubes, close the diffuser.
- 8. Turn on the power.





WARNING

- 1. These lamps should be installed by a licensed electrician.
- 2. These lamps should be used indoors(damp or dry locations only). Not suitable for wet location.
- 3. Make sure tombstones/lampholder are still in good condition and not defected before installation.
- 4. Ensure the brand and model no. of the ballast of replacement tube are in our compatible ballast list.
- 5. Make sure the ballast is working and still under warranty before installation.
- 6. Put LED tubes/G13 pins into right position of the socket, install properly.
- 7. This device is not suitable for using with emergency exits.
- 8. These lamps are not suitable to be used with a light dimmer.

If the LED lamp damaged by any one you didn't comply with above warning. We'll not responsible for that.