



⚠ WARNING

- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- To reduce the risk of death, personal injury, or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards, read all warnings and instructions included with and on the fixture box and all fixture labels.
- Proper grounding is required to ensure safety.
- Power must be turned off at the breaker before installation or maintenance.
- Installation, service, and maintenance of luminaires should be performed by a qualified licensed electrician.
- Wear gloves and eye protection at all times while installing, servicing, or performing maintenance on the luminaire, and avoid direct eye exposure to the light source while it is on.
- Do not install damaged product. Inspect luminaire for damage that may have occurred during transit. If damaged, contact the manufacturer immediately.
- These instructions do not purport to cover all details or variations in equipment nor to provide every possible contingency to meet in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's or owner's purposes, contact the manufacturer.

⚠ ADVERTENCIA

- Antes de instalar, reparar o realizar el mantenimiento de rutina de este equipo, siga estas precauciones generales.
- Para reducir el riesgo de muerte, lesiones personales o daños a la propiedad por fuego, descarga eléctrica, caída de piezas, cortes / abrasiones y otros peligros, lea todas las advertencias y instrucciones incluidas cony en la caja del dispositivo y todas las etiquetas del dispositivo.
- Se requiere una conexión a tierra adecuada para garantizar la seguridad.
- Se debe apagar la energía en el disyuntor antes de la instalación o el mantenimiento.
- La instalación, el servicio y el mantenimiento de las luminarias deben ser realizados por un electricista autorizado y calificado.
- Utilice guantes y protección para los ojos en todo momento durante la instalación, el servicio o el mantenimiento de la luminaria, y evite la exposición directa de los ojos a la fuente de luz mientras está encendida.
- No instale un producto dañado. Inspeccione la luminaria en busca de daños que puedan haber ocurrido durante el tránsito. Si está dañado, comuníquese con el fabricante de inmediato.
- Estas instrucciones no pretenden cubrir todos los detalles o variaciones en el equipo ni proporcionar todas las posibles contingencias a cumplir en relación con la instalación, operación o mantenimiento. Si desea obtener más información o si surgen problemas particulares que no están suficientemente cubiertos para los propósitos del comprador o propietario, comuníquese con el fabricante.

⚠ AVERTISSEMENT

- Avant d'installer, d'entretenir ou d'effectuer une maintenance de routine sur cet équipement, veuillez suivre ces précautions générales.



OUTDOOR POWER STAKE W/ MECHANICAL TIMER SAFETY AND INSTALLATION INSTRUCTIONS

- Pour réduire le risque de décès, de blessures corporelles ou de dommages matériels dus à un incendie, un choc électrique, des chutes de pièces, des coupures/abrasions et d'autres dangers, lisez tous les avertissements et les instructions inclus avec et sur la boîte du luminaire et toutes les étiquettes des luminaires.
- Une mise à la terre appropriée est requise pour assurer la sécurité.
- L'alimentation doit être coupée au niveau du disjoncteur avant l'installation ou l'entretien de cet équipement.
- L'installation, l'entretien et la maintenance des luminaires doivent être effectués par un électricien qualifié et agréé.
- Portez des gants et des lunettes de protection à tout moment lors de l'installation, de l'entretien ou de la maintenance du luminaire, et évitez de regarder directement la source lumineuse lorsqu'elle est allumée.
- N'installez pas de produit endommagé. Inspectez le luminaire pour vérifier s'il présente des dommages qui ont pu se produire pendant le transport. S'il est endommagé, contactez immédiatement le fabricant.
- Ces instructions ne prétendent pas couvrir tous les détails ou variations de l'équipement ni fournir toutes les éventualités possibles que vous pourriez rencontrer en rapport avec l'installation, l'exploitation ou la maintenance. Si vous souhaitez des informations supplémentaires ou si des problèmes particuliers surviennent et qu'ils ne sont pas suffisamment couverts pour les besoins de l'acheteur ou du propriétaire, contactez le fabricant.

WARNING

- Use only with outdoor equipment or seasonal decorations.
- Not for permanent use. Do not install or use this product for more than a 90-day period. If using an outdoor-use cord set for an extended period of time (greater than 90 days), please consider hard wiring a permanent, outdoor-use receptacle rated for year-round use in the area that power is needed.
- Do not exceed the maximum amperage rating of 15 Amps, or maximum wattage rating of 1,875 Watts.
- Cancer and reproductive harm – www.P65Warnings.ca.gov


CAUTION

- If using with products that are not marked with an ampere rating, connect no more than 140 screw-base lamps (C7 or C9) or 12 mini light strings to this power stake.
- This product should be plugged into a GFCI receptacle.
- Suitable for indoor and outdoor use. Store indoors while not in use.
- The connector body should be maintained a minimum of 6 inches above the ground.
- This is not a surge protector.
- Do not coil the power cord when in service.



Installation Instructions


- Connect the two pieces of the yard stake together by screwing Lower Stake (C) into Upper Stake (B).
- Attach the assembled stake to the Connector Body (A) by screwing the top of Upper Stake (B) into the base of the Connector Body (A).
- Be sure to firmly tighten the assembled stake to the Connector Body (A) before installing into the ground.
- The connector body (A) shall be maintained at minimum of 6 inches above the ground.
- Plug the power cord into a GFCI receptacle. The power cord is a 6ft 14/3 SJTW cord.






Operating Instructions

- This outdoor mechanical timer has 48 pins with daily repeat function.
- To set the current time, turn the dial clockwise and set the “TIME” arrow to the current time.
- Note: Day hours are highlighted in the white area and night hours are highlighted in black area.
- Set the desired ON/OFF times (see below).
- Pulling up the gray tabs will turn OFF the connected devices. Pushing down the gray tabs will turn ON the connected devices.
- Best practice is to pull the ALL gray tabs up (OFF) then pushing down the gray tabs to specify the time the connected devices are desired to be ON.
- Each segment pin represents 30 minutes (2 segment pins = 1 hour).
- You may program as many desired ON/OFF times for your appliance as you want.
- To override the timer, turn the switch to the ON position. This will allow the power supply to always be ON. Be sure to toggle the switch back to the TIMER position for the timer to be activated.



1. Cover
2. Timer dial:
3. Outlets:
Plug the lights or devices to be controlled by the yard stake into one of the outlets.
4. Switch:
Always ON or Timer Control



Troubleshooting

- The Connector Body (A) doesn't turn on – Make sure the AC power cord is securely plugged into an AC receptacle. Unplug the unit for a moment, and then plug it back in again. Check the receptacle by plugging in another device.
- In case of overloading, this product is equipped with a circuit breaker which will shut off all power. Eliminate the overload and then push to reset the circuit breaker for overload protection.