


INSTALLATION GUIDE MODEL #: EIN-CL57WH-1000e

Questions?

For customer service please call us at 1-310-787-1100 Office Hours: 8:00 a.m. – 5:00 p.m. PST Monday-Friday

www.eurilighting.com



PLEASE REVIEW THE INSTRUCTIONS AND WARNINGS LISTED BELOW PRIOR TO PROPER INSTALLATION

WARNINGS CAUTIONS For your safeth

- Risk of Fire-supply conductors(power wires)connecting the fixture must be rated minimum 90°C If uncertain consult an electrician.
- Risk of Electric Shock-Disconnect power at fuse of circuit breaker before installing or servicing.
- Risk of Fire/Electric Shock-If not qualified, Consult an electrician.

INSTALLATION INSTRUCTIONS

- For your safety read and understand instructions completely before starting installation.
- These luminaires (fixtures) are designed to meet the latest NEC require ments and are listed in full compliance with UL 1598.
- Before attempting installation, check your local electrical code, as it sets the wiring standards for your locality.

Outlet Box (by others) Mounting bracket (Only needed for 3 inch junction box) Mounted Screw Keyholes Disk Light Mounted Screw Lens

HOUSING INSTALLATION

Attach two mounted screws into outlet box leaving enough of screw exposed two engage keyholes in the top of disk light (Fig.1).

ELECTRICAL CONNECTION

- Provide electrical service according to the "National Electrical Code" or your local electrical code to the outlet box.
- 2. Connect supply wires to fixture wires and insulate with proper size wire nuts(Fig.1).
 - a.)Connect incoming ground wire(green or bare) to fixture ground wire(green or bare).
 - b.)Connect incoming common (white)wire to fixture common(white).
 - c.)Connect incoming hot(typically black) wire to fixture black wire.

LENS INSTALLATION

1. Twist the lens on disk light metal enclosure and lock the lens in place