bodine

Auxiliary Power

Generator Products

BLCD16DIM



Emergency Lighting Control Device 0-10 VDC Dimmer Override Supports lighting loads up to 16A

Product order number: BLCD16DIM

12NC number: 913702478401

Project:		
Location:		
Cat.No:		
Туре:		
Qty:		
Notes:		

Specifications

UL Listed for US and Canada

UL 924 Emergency Lighting Compliant Field Installation (Indoor and Damp)

Full Warranty

5 Years

Input Voltage

120-277 VAC, 50/60 Hz

LED Lighting Load Rating

Up to 16A electronic ballast rating

Temperature Rating (Ambient)

-35°C to +60°C (-30°F to +140°F)

Relative Humidity Range

5 to 95%, (noncondensing)

Housing

UL accepted for use in Plenum, NEMA 1

Wire

16", 600V Rated

Dimensions

4.0"x 4.0"x 1.81" with a 1/2" threaded nipple (102 mm x 102 mm x 46 mm)

Weight


0.675 lbs.

Benefits

- Allows generator supplied emergency lighting regardless of wall switch position
- Energy cost savings benefits by elimating constant night lighting
- LED rating Up to 16 Amp electronic ballast rating
- Small size Can be mounted on standard junction box
- 0-10 VDC dimmer override
- Plenum Rated (UL 2043)
- Interfaces with fire alarm panel or security system

Dimensions

4.0" x 4.0" x 1.81"





BLCD16DIM

Generator Product

Application

The BLCD16DIM works in conjunction with an auxiliary generator or central inverter system. The unit is designed to control lighting in areas where emergency lighting fixtures are connected on dedicated emergency lighting circuits that are typically on 24 hours per day. The BLCD16DIM allows normal control of emergency lighting for energy savings and/or task related reasons while strictly adhering to National Electric Code (NEC) requirements. It is suitable for any application where enhanced energy saving of emergency lighting is desired.

Operation

The BLCD16DIM senses the loss of normal power and switches the lighting load on, connecting it to a user designated emergency circuit. The BLCD16DIM can be used to override a 0-10V dimmer to full brightness. No routine maintenance is required to keep the BLCD16DIM functional; however, like other life safety unit equipment, it should be checked periodically to ensure that it is working properly.

Installation

The BLCD16DIM does not affect normal fixture operation and comes fully assembled for immediate installation. In addition to available wiring, the device requires a direct, unswitched connection to a normal power circuit and, depending on the application, an unswitched connection to a generator-supplied or central inverter system-supplied emergency panel. See wiring diagram for typical installation. UI And Code Compliance The BLCD16DIM has been tested by Underwriters Laboratories in accordance with the standards set forth in UL 924 as "Emergency Lighting Equipment" and UL 2043 as plenum rated. The BLCD16DIM is UL and cUL listed for field installation in the US and Canada.


Specification

Emergency egress lighting shall be provided by using existing lighting loads equipped with a Bodine BLCD16DIM emergency lighting relay control unit. The unit shall be capable of controlling dedicated emergency lighting fixtures and energizing them

when normal utility power has been lost. The unit shall consist of relay switching circuitry, a test switch, normal and emergency power indicator lights contained in one $4^{\prime\prime}$ x $4^{\prime\prime}$ x $1.81^{\prime\prime}$ enclosure; shall sense normal power at 120-277 VAC, 50/60 Hz; and be rated for 120-277 VAC, 50/60 Hz at up to 16 amps of lighting load. The unit shall be UL Listed for field installation and shall be warranted for a full five years from date of purchase.

Warranty

The BLCD16DIM emergency lighting control unit is warranted for five (5) full years from date of purchase. Please see detailed warranty information on our website.





© 2024 Signify Holding. All rights reserved. The information provided herein is subject to change, without notice. Signify does not give any representation or warranty as to the accuracy or completeness of the information included herein and shall not be liable for any action in reliance thereon. The information presented in this document is not intended as any commercial offer and does not form part of any quotation or contract unless otherwise agreed by Signify.

Signify North America Corporation 400 Crossing Blvd, Suite 600 Bridgewater, NJ 08807 Telephone: 800-500-0055 Signify Canada Ltd. 281 Hillmount Road, Markham, ON, Canada L6C 2S3 Telephone: 800-668-9008

All trademarks are owned by Signify Holding or their respective owners.