



WARNING

- Installation, service, and maintenance of luminaires should be performed by a qualified licensed electrician.
- Check the luminaire for damage that may have occurred during shipping. If the luminaire is damaged, contact the manufacturer.
- Read all installation instructions carefully and check to ensure all components and accessories are present. Once confirmed, install the fixture according to the installation steps.

CAUTION

- Do not use any electric generator to test this fixture.
- In the event of smoke or fire, turn off the power immediately and contact a qualified electrician.
- Use a listed waterproof strain relief bushing when connecting the power cord to the junction box.

Installation Instructions

Chain Mount w/ Ring or Hook

- Step 1. Screw the ring or hook into the fixture and tighten it securely (Figure 1).
- Step 2. Hang the fixture on the ceiling hook or chain (Figure 2).
- Step 3. Connect the fixture wires to the mains according to local regulations, ensuring that the connection is stable and well protected.
- Step 4. Install the safety cable (optional). Attach the safety cable buckle to the appropriate ceiling structure (Figure 3)



Figure 1




Figure 2




Figure 3



COLOR/WATTAGE SELECTABLE UFO LED HIGH BAY (PLT-13139)

WARNING, CAUTION, SAFETY AND INSTALLATION INSTRUCTIONS

Wiring Diagram

<p>ACL: Black ACN: White ⊕Ground: Green DIM(+): Purple DIM(-): Pink</p>	<p>NOTE: For the wire color of DIM+ & DIM-, check the fixture wire label.</p>
---	---

Compatible Dimmers

This fixture has 0-10V dimming. See the list of recommended dimmers below:

Brand	Model
LUTRON	NTSTV-DV
LEVITON	DS710-10Z / IP710
LEGRAND	RH4FBL3PW

Please choose the appropriate dimming way according to your needs. You can also choose not to use this function.

NOTE: The product cannot be connected to a dimming device when it's equipped with a motion sensor.

Field-Adjustable Wattage & CCT

The color temperature and lumen output can be adjusted by the two DIP switches located on the fixture housing. Each DIP switch has 3 options (left, middle and right), allowing 3500K (Natural White), 4000K (Cool White), 5000K (Daylight) and 3 wattages (low, medium or high).

<p>Factory Default Settings:</p> <ul style="list-style-type: none"> • Model: 300W/240W/200W Selectable • Default Settings: 300W, 5000K <p>Setting the Wattage & CCT:</p> <ol style="list-style-type: none"> 1. DIP switches are located on the fixture housing (Figure 4). 2. Remove the plug on the fixture housing. 3. Select a wattage and color temperature by sliding each switch to the desired value. 4. Put the plug back on the fixture housing. 	<p>Figure 4</p>
---	-----------------



⚠ WARNING

- Before installing, servicing, or performing routine maintenance upon this equipment, follow these general precautions.
- To reduce the risk of death, personal injury, or property damage from fire, electric shock, falling parts, cuts/abrasions, and other hazards, read all warnings and instructions included with and on the fixture box and all fixture labels.
- Proper grounding is required to ensure safety.
- Power must be turned off at the breaker before installation or maintenance.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Wear gloves and eye protection at all times while installing, servicing, or performing maintenance on the luminaire, and avoid direct eye exposure to the light source while it is on.
- To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.
- Do not install damaged product. Inspect luminaire for damage that may have occurred during transit. If damaged, contact the manufacturer immediately.
- These instructions do not purport to cover all details or variations in equipment nor to provide every possible contingency to meet in connection with installation, operation, or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's or owner's purposes, contact the manufacturer.

⚠ ADVERTENCIA

- Antes de instalar, reparar o realizar el mantenimiento de rutina de este equipo, siga estas precauciones generales.
- Para reducir el riesgo de muerte, lesiones personales o daños a la propiedad por fuego, descarga eléctrica, caída de piezas, cortes / abrasiones y otros peligros, lea todas las advertencias y instrucciones incluidas con y en la caja del dispositivo y todas las etiquetas del dispositivo.
- Se requiere una conexión a tierra adecuada para garantizar la seguridad.
- Se debe apagar la energía en el disyuntor antes de la instalación o el mantenimiento.
- Este producto debe ser instalado de acuerdo con el código de instalación aplicable por una persona familiarizada con la construcción y operación del producto y los peligros involucrados.
- Utilice guantes y protección para los ojos en todo momento durante la instalación, el servicio o el mantenimiento de la luminaria, y evite la exposición directa de los ojos a la fuente de luz mientras está encendida.
- Para evitar daños o abrasiones en el cableado, no exponga el cableado a bordes de láminas de metal u otros objetos afilados.
- No instale un producto dañado. Inspeccione la luminaria en busca de daños que puedan haber ocurrido durante el tránsito. Si está dañado, comuníquese con el fabricante de inmediato.
- Estas instrucciones no pretenden cubrir todos los detalles o variaciones en el equipo ni proporcionar todas las posibles contingencias a cumplir en relación con la instalación, operación o mantenimiento. Si desea obtener más información o si surgen problemas particulares que no están suficientemente cubiertos para los propósitos del comprador o propietario, comuníquese con el fabricante.