

Battery Operated Mixed Cedar Decorative Christmas Greenery

DESCRIPTION

Get any room or outdoor space ready for the holiday season with these battery-operated Mixed Cedar wreaths and garlands. Accented with real pinecones and twigs for a more life-life appearance, this collection of Christmas greenery is pre-lit with dual-function LEDs.

FEATURES

- · Designed for indoor and outdoor use
- · UV treated to resist fading in the sun; weatherproof
- Accented with real pinecones and twigs
- Comes pre-lit with dual-function LEDs, switch between white and multicolor using dial controller on battery box
- · If one bulb burns out, the rest will stay lit
- Battery box has stainless steel connections and is sealed with a rubber gasket
- Built-in timer feature helps extend battery lift; 6 hours ON, 18 hours OFF
- Garlands have bendable center wire that allows for easy shaping

ELECTRICAL

Battery Type: D# of Batteries: 3

Timer: 6 hours ON, 18 hours OFF

CONSTRUCTION

- Greens made from synthetic, PE, and PVC
- · Real pinecones and twigs

WARRANTY

2-year limited warranty; see pltsolutions.com for warranty details

Project name	Туре
Catalog number	
Comments	Voltage
Approved by	Date



APPLICATIONS

- Porches
- Patios
- Entryways
- Doorways
- Mantles
- Columns
- Offices
- Hotels
- Living Spaces
- Floral Arrangements
- Centerpieces

PERFORMANCE SUMMARY

Item #	Description	Pre-lit	Bulb Type	# of Bulbs	Power	Battery Type	# of Batteries	Timer	# of Tips
PLT-20321	30" Wreath	Yes	White & Multicolor LEDs	40	Battery Operated	D	3	6 Hours ON 18 Hours OFF	120
PLT-20322	6' Garland	Yes	White & Multicolor LEDs	35	Battery Operated	D	3	6 Hours ON 18 Hours OFF	138
PLT-20323	9' Garland	Yes	White & Multicolor LEDs	50	Battery Operated	D	3	6 Hours ON 18 Hours OFF	210

DIMENSIONS

PLT-20321

Diameter - 30"



PLT-20322

Length - 6' Width - 5"



PLT-20323

Length - 9' Width -14"



TIPS

- To shape, gently pull all branches so they are perpendicular from the spine, then using your hands gently "brush" the branches in the same direction in one sweeping motion 3 to 4 times.
- Store in a cool, dry place.
- If the product gets dirty, spray it with water and wipe with a soft cloth. Do not use abrasive detergents.