THE HANDHELD REMOTE CONTROLLER



ON OFF	ON Turn on OFF Turn off
ID	**Matching code for light** Long pressing the 'ID' button will keep the controller's indicator on, then turn on the light and release the 'ID' button after the light flashes, matching code complete. Matching code for several lights simultaneously is available.
ID + ▼	**Release the code and disconnect light from remote controller** Press the botton ID + ▼ together, then turn on the light, the light will flash to finish releasing the code on the lights.
1 2 3 4	**Group selecting button** Grouping lights (matching code process needs to be completed first). Turn off the lights, continue pressing the group selection button for 3s, then turn on the lights, the lights will flash to finish grouping.
	Turn-off delay Press the button, the delay function will begin after the light flashes once. The light will be turned off after 10s. Pressing the 'ON' button will cancel the delay function.
ALL	**All Groups are selected**

Color temperature selecting/saving
After selecting the color temperature, press the button "OFF" then turn on the light to save the color temperature.

5000K	3500K
4000K	3000K
25% brightness	75% brightness
50% brightness	100% brightness
Increase brightness	Decrease color temperature
Decrease brightness	Increase color temperature

* After turned on, the light will automatically detect the 0-10v dimmer setting to determine the brightness. It will default to 100% brightness if there is no dimmer input.

* If the dimmer is used, the light brightness will convert to 0-10v dimmer's current brightness setting.

* If the remote controller is used, the light brightness will only change from its current brightness.

THE WALL TYPE REMOTE CONTROLLER



ON OFF	ON Turn on OFF Turn off
A	Brightness adjustor
CCT	Press the 'CCT' button, the color temperature will cycle between 3000k/3500k/4000k/5000k. After shutting down/turning off the current color temperature will be saved.
ON + OFF	Light code combination matching button Pressing the 'ON + OFF' buttons simultaneously will keep the remote controller's indicator on, turn on the light and release the buttons after the light has been on for 2s completing the matching process. Matching code for several lights together is available. If you need to use both hand-hold controller and wall controller for the same light, please don' use this function, directly use the following copy function.

The matching method of hand-hold remote controller and wall-type remote controller, the wall controller can copy some of the functions of the hand-hold controller by the following method.

NO.	Grouping	Hand-hold controller	Wall-type controller
1	1	1 + ID	ON+CCT
2	2	2 + ID	ON+CCT
3	3	3 + ID	ON+CCT
4	4	4 + ID	ON+CCT
5	All	ID	ON+CCT

After 10s of each operation the light will enter standby power saving mode. If you need to make adjustments, simply press the 'ON' button, the indicator will flash to show it is working.