

METAL LAMP CORD SUPPORT CLIP

USING THE ADAPTOR AND SUPPORT CLIP

The Xtrasun Ballast comes pre-wired with a new dual lamp receptacle, which allows you to plug in all common reflectors without the use of an adapter plug. Perform the following with the reflector unplugged.

1. Slide the attached plastic cover on the adapter over the unused side. Plug in the Xtrasun to the correct lamp receptacle (already attached to the ballast).
2. Spread the two metal prongs of the metal support clip (included in the hardware bag) apart so they fit over the holes on either side of the plug. The holes are in the grooved portions of either side of the reflector lamp cord head. It may be helpful to move the piece of black plastic blocking the outlet not in use.
3. Hook the attached metal support clip (included in the hardware bag) over the lamp cord to prevent the plug and cord from being detached while in use.



WARNINGS

- Do not place the open ends of the metal support clip into the power receptacle or any power supply.
- Do not place the open ends of the metal support clip into the fins or any other openings on the ballast.
- Do not use the metal support clip to attach or pin down any other cords.