

  
bluelab®  
pH controller

## Care and use guide



\*6 months  
for pH probe

CE FC



# Contents

	page		page
Features	3	Set the dose direction - for pH up or down solution	12
Bluelab pH Controller	3	Set the dosing OnTime and Off Time	13
What's in the box?	4	Set alarms (optional)	14
<b>IMPORTANT - Bluelab pH Probe care</b>	5	View current settings	14
Installing the pH controller	6	Priming the pump	15
Connect the Bluelab pH Probe	6	Set the mode	15
Connect the Bluelab Temperature Probe	6	Change the screen backlight and/or contrast	16
<b>SAFETY - Handling pH up or pH down solution</b>	6	Hydrating the pH probe	16
Set up inlet dosing tube	7	Cleaning the pH probe	17
Set up outlet dosing tube	7	Troubleshooting guide	18
Connect power adaptor	8	Frequently Asked Questions (FAQs)	19
Display menu and buttons	8	Technical specifications	20
Factory settings	9	Bluelab pH Controller accessories and spare parts	21
Change the display language	9	Limited product guarantee	23
pH calibration	10	Limitation of liability	23
Placement of the probes	12	Contact details	23
Set the required pH	12		



# Features


Automatic control and monitoring of system pH with reservoirs up to 200 US Gallons / 760 Liters	Auto resume dosing on restart after power loss
Large, easy to read display	Water resistant, wall mount design
Simple push button pH calibration with on screen instructions	13 foot (4 meter) acid/alkaline resistant tubing supplied
Easy to navigate menu to program and adjust settings	International power supply
Flashing high and low alarm with safety control lockouts	Replaceable double junction pH probe
'Plant-safe' green back lit LCD with adjustable brightness and contrast	Separate Bluelab Temperature Probe (for pH ATC)
Dosing lockouts to protect from over-dosing	Replaceable peristaltic pump and tubing



**What is Plant Safe?** Green lights are safe for continued growth during a plant's fruiting stage when hours of darkness are required.

**What are Dosing Lockouts for?** They are a built-in safety feature that stops pH dosing if an error is detected in the system (see FAQs for more detail).

## Bluelab pH Controller



### ATTENTION

If it dries, it dies!



Keep your pH probe tip wet at all times to avoid permanent damage

## 1.0 What's in the box?

Please verify the box contents from the information below.



- 1 Bluelab pH Controller
- 2 Bluelab pH Probe with storage cap
- 3 Bluelab Temperature Probe
- 4 Bluelab pH Probe holder with suction cup
- 5 24V DC 0.4Amp power supply
- 6 Europe plug adaptor
- 7 UK plug adaptor
- 8 North American plug adaptor
- 9 NZ / Australia plug adaptor
- 10 13 foot (4 meter) Acid/Alkali resistant dosing tube with connectors
- 11 4 x mounting fasteners
- 12 20ml pH 7.0 and pH 4.0 single-use calibration solution sachets
- 13 Inlet tube cap for pH stock solution
- 14 Replaceable peristaltic pump with cover





## 2.0 IMPORTANT - Bluelab pH Probe care

*pH probes DO NOT last forever. They age through normal use and will eventually fail. The life time of a pH probe depends on the environment it is used in and the way that it is treated. To receive a long life from your Bluelab pH Probe, please ensure you follow the guide below.*

**pH probes contain glass and are therefore FRAGILE. With good care, they will give a long service life.**

### Bluelab pH Probe



**DO NOT** let the pH probe tip dry. IF IT DRIES IT DIES!

**DO NOT** bend the probe; this will break its internal glass tube.

**DO NOT** knock the probe; this will break its internal glass tube or external glass bulb.

**DO NOT** plunge a cold pH probe into a hot liquid, or a hot probe into cold liquid. Sudden temperature changes can crack the glass and permanently damage the probe.

**DO NOT** immerse in oils, proteins or suspended solids that will leave a coating on the glass bulb.


**DO NOT** 'kink' or bend the lead sharply.

**DO NOT** attempt to lengthen the lead on the pH probe.

**DO NOT** wet the BNC connector at the end of the lead.

### Always remove pH probe storage cap before use

1. Grip the top of the cap and gently twist the base one rotation clockwise to loosen slightly.
2. Next slowly slide the cap off the pH probe. DO NOT completely remove the base of the cap from the top of the cap.
3. Store the storage cap in a safe place.



Removing pH probe storage cap


### Storing the pH probe

**When storing the pH probe, the pH probe tip must be kept moist.**

To prepare the pH probe for storage, add enough Bluelab pH Probe KCl Storage Solution to the storage cap so the probe tip is covered. Then replace the cap and store in a secure place. DO NOT use RO (Reverse Osmosis), Distilled or De-ionized water. Pure water changes the chemistry in the reference, causing the probe to die.

### If the pH probe has been accidentally allowed to dry out;

The pH probe must be 'hydrated' for 24 hours in KCl storage solution (never use RO, Distilled or De-ionized water). Following this; carry out a calibration to check if the probe has already suffered permanent damage.



Ensure probe tip is covered by the KCl storage solution in cap



### 3.0 Installing the pH controller

- Select a suitable location that is:
  - Less than 5.65 feet / 2 meters from your reservoir. The probes must be immersed in solution at all times.
  - Less than 4.9 feet / 1.5 meters from an electrical mains outlet.
  - Less than 5.56 feet / 2 meters from pH Up or Down solution. The inlet tube must reach the bottom of the container.
  - At a suitable height to see the display and for easy operation (recommend slightly below eye level when standing).

**NOTE:** Avoid placing the pH controller where it can be damaged by direct sunlight, water, nutrient salts or pH adjuster.

- Fix the fasteners through the desired mounting holes in the top and bottom of the case.



### 4.0 Connect the Bluelab pH Probe

- Connect the pH probe to the pH controller by lining up the lugs of the BNC fittings.
- Fasten securely by pushing the pH probe connector on and twisting one quarter turn.



### 5.0 Connect the Bluelab Temperature Probe

- Insert the temperature probe connector to the base of the pH controller where 'ATC' is labelled. Ensure the connector is fully inserted.



### 6.0 SAFETY - Handling pH up and down solutions

- Bluelab pH Up or pH Down Solutions are available in North America. They can be used undiluted with the pH controller. Always follow the manufacturer's instructions for use and handling.

**CAUTION:** Wear eye protection and gloves when handling this product. Harmful if swallowed. Keep out of the reach of children. Store under cool and dry conditions. Not for food, drug or household use. Read MSDS before use.







## 7.0 Set up inlet dosing tube

1 **To straighten tube:**  
Bend tube in the opposite direction and straighten by running through closed fingers.

2 Insert one end of the dosing tube with connector into the **LEFT** peristaltic pump tube. This is the 'inlet dosing tube'.




3 Ensure the inlet dosing tube will reach the bottom of the pH stock solution container. *There also needs to be enough tube left for the outlet dosing tube to go into the reservoir/tank.* Cut the inlet dosing tube to the desired length. Use inlet tube cap supplied to place on BlueLab Up or Down 500ml or 1 Liter bottles. This will hold the tube in position. Insert the inlet dosing tube through the hole in the cap and pierce the induction seal on the bottle.




## 8.0 Set up outlet dosing tube

1 Insert the remaining dosing tube with connector into the **RIGHT** peristaltic pump tube. This is the 'outlet dosing tube'.



2 Cut the outlet dosing tube so that the tube sits above the maximum solution level of the reservoir/tank. The pH stock solution **must** drip into the nutrient reservoir/tank.

**Note:** *If the outlet dosing tube is immersed in reservoir/tank solution, it could create a syphon. This would cause the pH stock solution to overflow.*





## 9.0 Connect power adaptor

- 1 Select and connect the appropriate mains plug adaptor for your country to the power supply unit.
- 2 Connect the power adaptor into the base of the pH controller where 'PWR' is labelled. Plug the adaptor into mains power supply.
- 3 Switch on power adaptor at the mains. The pH controller will complete a display test sequence.
- 4 The default setting, when the unit is first powered up, is 'monitoring' mode.  
**Note:** pH calibration must be completed before the first use, see section 13.0.



connect power adaptor



## 10.0 Display menu and buttons

- 1 One press of the 'menu' button will take you into the menu. To exit the menu, press 'menu' again. Changes will not be saved.
- 2 The '^' (up arrow) button allows you to move up the menu items or increase a value shown.
- 3 The 'v' (down arrow) button allows you to move down the menu items or decrease a value shown.
- 4 The 'enter' button allows you to select the desired option shown on the display, or save a chosen value.
- 5 The 'cal' button is used to calibrate your pH probe. A long press enters the calibration sequence.



- 6 The following symbols, numbers or characters will show on the display to indicate:

Reading display

- Alarm is on (bell icon)
- pH control direction - up OR down (up/down arrow icon)
- Successful pH calibration indicators (pH 7.4 and pH 7.10)
- Automatic Temperature Compensation if Temperature Probe is connected (ATC)
- pH controller status, menu options or instructions (ABCDEF...)

- 7 To use the 'Auto-repeat' feature: Press and hold the '^' (up arrow) or 'v' (down arrow) button to scroll through options. Release when you see the desired option or value on the screen.







## 11.0 Factory settings

1 The pH controller is set to the following values by default:

- |              |           |                  |         |
|--------------|-----------|------------------|---------|
| • Mode       | Monitor   | • OffTime        | 10Min   |
| • Set pH     | 5.8       | • Backlight      | 100% On |
| • Alarm      | On        | • Contrast       | 16      |
| • HighAlarm  | 6.5       | • 2/3pt Cal      | 2       |
| • LowAlarm   | 5.6       | • EarthLink      | Off     |
| • Dose Up/Dn | Down/Acid | • Language       | eng     |
| • OnTime     | 1Sec      | • pH Calibration | none    |

**Note:** 'Pump runtime' [HH:MM:SS] is the time the pump has dosed for. 'Product runtime' [Hrs] is the duration of time the pH controller has been in use for. Pump runtime and product runtime are never reset, even after pump replacement.

2 To restore the pH controller to the above factory settings at any stage:

- Disconnect the power
- Press and hold the 'cal' button then reconnect the power.
- When 'Restored Factory Defaults' is displayed on the screen, release the 'cal button'.

## 12.0 Change the display language

1 Press 'menu'. Press 'v' to find language. Press 'enter' to select.

2 Press 'v' or '^' to find the required language.

3 Press 'enter' to save the language selection. Press 'menu' to exit the menu.





## 13.0 pH calibration

pH calibration is important before first use. It ensures pH measurements and/or pH stock solution dosing is accurate. *The BlueLab Temperature Probe DOES NOT require calibration.*

### For accurate pH readings the pH probe is cleaned and recalibrated when:

- It has been 30 days since the last pH calibration, and the successful calibration indicators are not showing.
- The reading is different to what you were expecting.
- The pH controller is reset to factory default.
- The pH probe is replaced with a new one.

*If the pH probe has been in use it must be cleaned before pH calibration. See pH probe cleaning in section 24.0. New pH probes do not need to be cleaned.*

### For best pH calibration

**pH reading accuracy is dependant on the accuracy and age of the calibration solutions used, and use and cleanliness of the pH probe tip.**

- Ensure the pH probe has been cleaned and rinse with clean water between calibration solutions to reduce contamination of the pH solutions.
- Only fresh uncontaminated solutions should be used.
- Calibrate the pH at the same temperature as the solution to be measured.
- ALWAYS calibrate the pH probe with pH 7.0 then to pH 4.0 and/or pH 10.0.
- Place the temperature probe into the calibration solution with the pH probe during calibration.

**The pH calibration involves cleaning the pH probe tip and then calibrating in TWO or THREE SOLUTIONS.**

**If you are calibrating to TWO solutions, remember:**

If a reading below pH 7.0 is expected, use pH 7.0 and pH 4.0 calibration solutions.

If a reading above pH 7.0 is expected, use pH 7.0 and pH 10.0 calibration solutions.

**You would require calibration in THREE solutions if:**

Readings above and below pH 7.0 are expected, use pH 7.0, pH 4.0 then pH 10.0 calibration solutions. You will need to enable 3 point calibration in the settings menu.

Follow the steps on the next page for pH calibration.

### Storage and use of calibration solutions

- Always place the lid back onto the bottle after use or evaporation will occur rendering the solution useless.
- DO NOT measure directly into the bottle. Tip a small amount into a clean container and discard after use.
- Never add water to solutions.
- Store in a cool place.



## 13.0 pH calibration cont.

### To calibrate the pH

#### 1 Clean pH probe tip.

See section 24.0 (the pH probe does not require cleaning before the first use).

#### 2 The calibration default is set at two point calibration. If a three point calibration is required:

- Press 'menu'.
- Press 'v' to find '2/3 point cal'. Press 'enter'.
- Press 'v' to select '3'. Press 'enter'. When 'saved' is displayed on screen, three point calibration is now available.

#### 3 In separate plastic containers, prepare a small amount of: fresh tap water, pH 7.0, pH 4.0 and/or pH 10.0 calibration solutions.

#### 4 pH 7.0 calibration

- Ensure the pH controller is plugged in.
- Press and hold 'cal' for three seconds. 'pH 7 Calibrate' will be displayed.
- Place the clean pH probe tip in the pH 7.0 calibration solution. Press 'cal'.
- Calibration is complete when all the '□'s on the screen become solid. The screen will display 'OK' and the 'pH 7' indicator will appear to indicate successful pH 7.0 calibration.
- Now you can calibrate to pH 4.0 and/or pH 10.0






#### 5 pH 4.0 and/or pH 10.0 calibration

- Rinse the probe tip in fresh tap water, shake off excess water. Place the clean pH probe tip in either pH 4.0 or pH 10.0 calibration solution. Press 'cal'.
- Calibration is complete when all the '□'s on the screen become solid. The screen will display 'OK' and the 'pH 4' or 'pH 10' indicator will appear to indicate successful pH calibration.
- If you require three point calibration, repeat '5a' and '5b' using the pH 4.0 or pH 10.0, whichever solution was not used.
- The pH controller is now calibrated, and ready for use.

#### 6 After pH calibration, the pH controller reverts to 'Monitor' mode.

Change to 'Control' mode if required.

**NOTE:** If 'Failed <e>' is displayed on the screen during calibration, see section 25.0 Troubleshooting.





## 14.0 Placement of the probes

The tip of the *Bluelab pH Probe* must be submerged in the liquid for a measurement to occur. It is optional to use the *Bluelab Temperature Probe*, but required for automatic temperature compensation (ATC) to occur, or to enable 'Earthlink'.

- Do not pour concentrated nutrient solution or pH adjuster directly onto probes when in the reservoir. Strong acids, alkali and nutrients damage the probes, trigger the alarms (if on), cause the pump to accidentally dose or stop dosing, or interfere with the control program.
- For accuracy, ensure the probes are in an area where the reservoir/tank solution is well mixed.
- pH and temperature probes can be fully submerged in the solution.

1 Fit the (optional) pH probe holder to the stem of the pH probe using a gentle twisting motion.

2 Place the pH probe into the reservoir/tank and push the suction cup onto the side of the reservoir but far enough down so the pH probe tip is always in the solution. This prevents damage to the probe from any movement in the reservoir/tank.

3 Place the temperature probe alongside the pH probe.



## 15.0 Set the required pH

1 Press 'menu'.

2 Press 'v' to find 'Set pH'. Press 'enter' to select.

3 Press 'v' or '^' until the required pH is shown in the main display. Press 'enter' to save the value.

**Note:** If you have already set high and low alarm values, you may see the values change depending on the pH value being set.



## 16.0 Set the dosing direction - for pH up or down solution

1 Press 'menu'.

2 Press 'v' to find 'Dose Up/Dn'. Press the enter button to select.

3 Press 'v' or '^' to select the dosing direction that matches the pH stock solution being used in the system. Press 'enter' to save.

**Note:** Select 'Dn/Acid' for acid (pH down solution). Select 'Up/Alkali' for alkali (pH up solution).





## 17.0 Set the dosing OnTime and OffTime

A dosing cycle includes the OnTime and the OffTime that the peristaltic pump doses the system for. The arrow symbol on the display will flash during the dose cycle. Adjustments for OnTime and OffTime will be required so that three dosing cycles only change the pH value by 0.1 pH.

- 'OnTime' is the length of time the peristaltic pump will dose for. The 'OnTime' can be set from 1 to 60 seconds.
- 'OffTime' is the delay time between each dose. This gives the system time to mix the pH stock solution thoroughly, so the pH controller can measure the changes being made before needing to dose again. The 'OffTime' can be set from 1 to 60 minutes.
- Start with a long 'OffTime' and adjust back as you go. The more thorough the mixing in the tank, the shorter the 'OffTime' can be.

### To set the OnTime value:

- 1 Press 'menu'.
- 2 Press 'v' to find 'OnTime'. Press 'enter'.
- 3 Press 'v' or '^' to select the dosing on time in **seconds**. Press 'enter' to save.



### To set the OffTime value:

- 1 Press 'v' to find 'OffTime'. Press 'enter'.
- 2 Press 'v' or '^' to select the dosing off time in **minutes**. Press 'enter' to save.





## 18.0 Set alarms (optional)

The alarm function alerts you when the solution deviates too far from the desired pH. When an alarm condition is present, the pH value and the alarm symbol will flash on the screen. This is an 'alarm lockout' state. All dosing will stop.

If the measurement changes back to within the limits you have chosen, the flashing will stop and dosing will start.

### To set the 'High Alarm' value:

- 1 Press 'menu'.
- 2 Press 'v' to select 'Alarm High'. Press 'enter'.
- 3 Press 'v' or '^' to select the desired value. Press 'enter' to save.



### To set the 'Low Alarm' value:

- 1 Press 'v' to select 'Alarm Low'. Press 'enter'.
- 2 Press 'v' or '^' to select the desired value. Press 'enter' to save.



### To turn on the alarm:

- 1 Press 'v' to find 'Alarm'. Press 'enter'.
- 2 Press 'v' or '^' to select 'On'. Press 'enter' to save the value and turn on the alarm. Press 'menu' to exit back to the main display.



## 19.0 View current settings / status

Use this option to view your programmed settings at any time.

- 1 Press 'v' or '^' while in 'monitor' or 'control' mode. The setting for each value is displayed at the bottom of the screen.
- 2 The display will revert to displaying 'Required pH' if no button is pressed after 1 minute.





## 20.0 Priming the pump / manual dosing

'Pump Ovrde' allows you to fill the inlet and outlet tubes with dosing solution before first use (removing any air in the tubes), and to manually dose the tank if required. Always ensure the inlet dosing tube reaches to the bottom of the pH stock solution container. Ensure the outlet dosing tube is above the highest water line so that pH stock solution drips into the tank/reservoir.

**NOTE:** If priming the pump, temporarily move the outlet dosing tube so it runs into the pH stock solution container (if not already fixed in place). This will avoid adding pH stock solution to your tank/reservoir unintentionally.

- 1 Press 'menu'.
- 2 Press 'v' to find 'Pump Ovrde'. Press 'enter' to select.
- 3 Press 'v' to manually operate the pump. Release the button to stop the pump when you see the stock solution begins to drip from the outlet dosing tube into the tank. Press 'menu' to exit.  
*If the outlet dosing tube was temporarily moved in step 1, place it back, so pH solution will drip into the tank/reservoir.*



**CHANGING STOCK SOLUTION:** If you are changing from pH Up to pH Down, or vice versa, you **MUST** flush the dosing tube with water **FIRST** to avoid a chemical reaction in the tube.

## 21.0 Set the mode

Use 'mode' to select the pH controller function. 'Monitor' mode shows the current solution pH reading. It is the factory default setting. 'Control' mode allows the pH controller to dose pH stock solution to the set values. Dosing will NOT occur when:

- The pH controller is in 'monitor' mode
- The pH controller is in an alarm state
- If the pH controller senses dosing is not having an effect on the system (after 15 dose cycles)
- The solution temperature is above 50 °C / 122 °F, or below 0 °C / 32 °F

### To set 'monitor' mode:

- 1 Press 'menu'.
- 2 Press 'v' to select 'Mode'. Press 'enter'.
- 3 Press 'v' or '^' to select 'monitor', then press 'enter' to save the mode. Press 'menu' to exit.



### To set 'control' mode:

- 1 Press 'menu'.
- 2 Press 'v' to select 'Mode'. Press 'enter'.
- 3 Press 'v' or '^' to select 'control', then press 'enter' to save the mode. Press 'menu' to exit.  
*The display will show a countdown before the pump can start. This is the 'Pump start delay', which is set to these times: 15Sec when exiting the menu with control mode enabled; 60Sec if power off/on occurs.*





## 22.0 Change the screen backlight and/or contrast

*These can be adjusted to best suit the light levels of the environment the pH controller is being used in.*

*Backlight can be set at 0%, 25%, 50%, 75% or 100%.*

*Contrast can be set between 0 and 30.*

### To change the screen backlight:

- 1 Press 'menu'.
- 2 Press 'v' to find 'Backlight'. Press 'enter'.
- 3 Press 'v' or '^' to select the desired value. Press 'enter' to save, then 'menu' to exit back to the main display.



### To change the screen contrast:

- 1 Press 'menu'.
- 2 Press 'v' to find 'Contrast'. Press 'enter'.
- 3 Press 'v' or '^' to select the desired value. Press 'enter' to save. Press 'menu' to exit.




## 23.0 Hydrating the pH probe

*Hydrate the pH probe in BlueLab pH Probe KCl Storage Solution when:*

- *the probe tip has not always been stored in KCl storage solution, to improve the reading response speed.*
- *the probe tip has been accidentally allowed to dry out.*

*Never store the pH probe in RO (Reverse Osmosis), De-ionized or Distilled water. Pure water changes the chemistry in the reference, causing the probe to die.*

- 1 **Clean the pH probe tip.** Ensure the probe tip is cleaned before hydrating. See section 24.0 for instructions.
- 2 **Add enough BlueLab pH Probe KCl Storage Solution to a plastic container to submerge the pH probe tip.**
- 3 **Loosen, then remove the storage cap (if required).** Place the pH probe upright in a the KCl solution.
- 4 **Leave to soak for up to 24 hours.** After hydration, always calibrate the pH probe to ensure accuracy, see section 13.0.





## 24.0 Cleaning the Bluelab pH Probe



To ensure accurate readings the pH probe tip needs to be rinsed in water and cleaned prior to calibration using the following instructions.

After cleaning, use the probe straight away, or place the storage cap on the probe tip. Always ensure the cap contains enough Bluelab pH Probe KCl Storage Solution to cover the probe tip.

### 1 Remove storage cap from pH probe.

Hold the top of the storage cap, twist the cap to loosen then remove.

### 2 Rinse pH probe tip under fresh tap water.



### 3 Fill a small plastic container with clean tap water.

Add a small amount of Bluelab pH Probe Cleaner or mild detergent (dishwashing liquid).

### 4 Gently stir the probe tip in the mixture.


Ensure that you do not 'knock' the pH probe on the side of the container as this may cause damage to the probe.

Rinse well under fresh running water to remove all traces of the detergent mixture.



### 5 If the probe tip requires removal of heavy contamination:


Gently brush around the glassware with a few drops of Bluelab pH Probe Cleaner or mild detergent (dishwashing liquid) and a soft toothbrush.



### 6 Rinse well under fresh running tap water to remove all traces of the detergent mixture.

### 7 Calibrate pH probe after cleaning, see section 13.0.

After calibration use straight away or store pH probe in the storage cap, ensuring there is enough KCl Storage Solution to cover the probe tip.





## 25.0 Troubleshooting guide

Trouble	Reason	Correction
<i>pH reading inaccurate</i>	pH probe not plugged in.	Connect pH probe. Check pH probe connection.
	Using factory default calibration.	Calibrate pH probe.
	Contaminated pH probe / glassware not clean.	Clean pH probe, then calibrate.
	Calibration old.	Calibrate pH probe.
	Broken glass bulb, tube or connector.	Replace pH probe.
	pH probe damaged or old.	Replace pH probe.
	Bad grounding (noisy/jumpy pH readings).	Earthlink required. Attach temperature probe. Go to Menu, turn Earthlink on.
<i>Display shows 'Failed &lt;e&gt;' during calibration</i>	Old or contaminated solutions used for calibration.	Use fresh calibration solutions.
	Dirty or contaminated pH probe.	Clean pH probe.
	pH probe tip been allowed to dry.	Hydrate pH probe.
	pH probe damaged or old.	Replace pH probe.
<i>No display</i>	Mains not switched on.	Switch mains power on.
	Power adaptor not plugged in.	Plug power adaptor into the power socket marked 'PWR'.
	Mains on, power adaptor plugged in.	Replace power adaptor.
<i>No display after initial LCD test, when plugged in</i>	Backlight set to minimum.	Increase Backlight setting in MENU, or hold <cal> button down while applying power, to restore Factory Defaults.
<i>pH displays 'or', 'ur', '-.'</i>	'or' Over range pH. 'ur' Under range pH.	Check pH probe connection. pH probe could be faulty. Clean pH probe, then calibrate.
	'-.' Temperature over/under range.	Solution <0 °C / 32 °F or >51 °C / 122 °F. Check solution temperature. Ensure temperature probe plug is fully inserted.
<i>Temperature displays 'or', 'ur', '-.'</i>	'or' Over range temperature. 'ur' Under range temperature. '-.' Temperature probe not connected.	Solution >51 °C / 122 °F. Solution <0 °C / 32 °F. Ensure temperature probe plug is fully inserted. Temperature probe is faulty, replace.
<i>pH symbols flashing</i>	It has been more than a month since last pH calibration.	Clean pH probe, then calibrate.
<i>'HELP' flashing [Ineffective control detected]</i>	Dosing solution container empty.	Refill dosing solution container.
	Dose direction setting incorrect for your system.	Ensure setting reflects dosing solution in use. i.e. For Acid select Down.
	Dose on/off times incorrect.	See section 17.0 for setting Dose On/Off times correctly.
	Output from tube not dripping into solution.	Ensure tube output drips into tank.
	Solution is not mixing.	Ensure pH correction solution is being mixed in tank.
	pH probe not seeing pH changes, after dosing	Ensure pH probe is in tank/reservoir solution with adequate mixing.

## 26.0 Frequently asked questions

Question	Answer
<b>Why is the '↑' or '↓' flashing but the pump is not turning?</b>	The '↑' or '↓' will flash when ever the pH controller is in a dose cycle. This includes the 'OnTime' and 'OffTime'. The pump does not turn during the 'OffTime'.
<b>What are dosing lockouts?</b>	A feature that stops the pH controller from dosing if: <ul style="list-style-type: none"> <li>• The temperature probe measures a solution temperature of less than 0 °C / 32 °F or more than 50 °C / 122 °F.</li> <li>• The pH reading does not change after 15 dose cycles.</li> </ul>
<b>Do I need to use the temperature probe with ATC for pH?</b>	You can omit use of the ATC probe if:- <ol style="list-style-type: none"> <li>1) You do not use EarthLink On setting to stabilise the pH value</li> <li>2) Your solution temperature is stable and you calibrate the pH probe in calibration solutions at the same temperature as the reservoir / tank solution.</li> <li>3) Your pH is close to 7.0 pH</li> </ol>
<b>Why should I use earthlink?</b>	To remove/reduce any "mains earthloop" issues affecting the pH value's stability.
<b>How do I use Earthlink?</b>	Ensure the ATC probe is installed and in the same solution as the pH probe. Press 'v' to view status of pH mV value behaviour. Change the Earthlink setting in MENU and watch the pH mV value again. Select the Earthlink option that gives the least pH mV noise/variation. If neither option improves pH stability: <ol style="list-style-type: none"> <li>1) Calibrate pH probe, see section 13.0.</li> <li>2) Suspect Mains electrical problems. Obtain Electrician assistance.</li> </ol>
<b>How do I determine the best Dose OnTime/ OffTime values?</b>	Adjust OnTime such that 3 to 5 doses shifts the pH by only 0.1pH. If <= 2 doses moves pH more than 0.1pH, you risk overdosing. (pH changes past Required Value). If it takes >=5 doses you will have a slow response to any changes. You may also get "HELP" displayed if pH hasn't moved enough if 15 dose cycles. If < 3 doses at 1 sec OnTime shifts the pH more than 0.1pH, you will need to dilute the dosing solution to a lower concentration.
	Adjust OffTime such that the last dose is fully mixed before the next dose cycle starts. If OffTime is too short, you risk overdosing (pH changes past Required Value). If OffTime is too long, correction to pH changes will take longer than necessary.
<b>How do I reset the pH controller to "as Shipped Defaults"?</b>	Hold <cal> button down and apply power. Release button when "Restored Factory Defaults" appears on screen.
<b>How do I reset pH calibration to "Defaults"?</b>	You shouldn't need to. The pH probe can be calibrated anytime to the pH controller. Follow the calibration steps in section 13.0.





## 27.0 Technical specifications

	<i>pH</i>
<b>Control parameter</b>	pH - user selectable single direction (up or down)
<b>Control range</b>	0.1 – 13.9 pH
<b>Dose rate</b>	10 ml per minute
<b>Resolution</b>	0.1 pH
<b>Accuracy at 25°C/77°F</b>	±0.1 pH
<b>Calibration</b>	Two or three point (pH 7.0 and pH 4.0, and/or pH 10.0)
<b>Temperature compensation</b>	Yes (if temperature probe is in the same solution as pH probe)
<b>Operating environment</b>	0 - 50°C / 32 - 122°F
<b>Power source</b>	<b>Input:</b> 100-240 Vac, 50-60 Hz, 5 VA, 4 interchangeable plug types (USA, Euro, UK, NZ/AUS) <b>Output:</b> 24VDC 0.4Amp
<b>Screen display languages</b>	English, Deutsch, Español, Français, Nederlands



# Bluelab pH Up and pH Down Solutions

Optimum growth needs optimum pH. And we make optimum simple.

If your pH isn't in the right range – and that's 5.5-6.5 for most plant varieties – your nutrients are likely wasted.

We say that's a problem you don't need. At Bluelab, we want our customers to have optimum growth and the best plants possible. So we've made it easy to raise or lower pH levels, whenever you need, and keep them just where they should be.

Bluelab's pH Up and pH Down are formulated to the highest standards. Just add what's required to lift or reduce growing solution acidity. Your plants will thank you for it. The main thing is, you'll see the difference in your harvest. Optimum inputs. Optimum results. Simple.



## Available in:



› Bluelab pH Up 500ml

› Bluelab pH Down 500ml

› Bluelab pH Up 1 Liter

› Bluelab pH Down 1 Liter

› Bluelab pH Up 1 Gallon

› Bluelab pH Down 1 Gallon

## Bluelab pH Probe replacement

pH probes do not last forever.

They age through normal use and will eventually fail.

To ensure you receive a long life from your pH probe, please read the instructions provided with it.

*When the time comes to replace your Bluelab pH Probe all you have to do is order a replacement from your supplier!*



## Bluelab Probe Care Kits

The instrument is only as accurate as the probe is clean!

Probe cleaning is one of the most important parts of owning and operating any Bluelab meter, monitor or controller.

If the probe is contaminated (dirty) it affects the accuracy of the reading displayed.

Bluelab Probe Care Kit range is available for:

- pH probe care
- pH & conductivity probe care
- Conductivity probe care

All the tools you need are included in each kit.

To re-stock your care kit, choose from the Bluelab Solutions range.



## Bluelab Probe Care Kit - pH contains:



› Probe care instructions

› Bluelab pH Probe Cleaner

› 3 x plastic cups

› Toothbrush (pH probe cleaning instrument)

› 20ml single-use Bluelab Solution Sachets, 2 each of: pH 7.0 & pH 4.0, KCl



## Bluelab Peristaltic Pump

Replacement pump motor, cover and tubing for Bluelab pH Controllers.

**Quick and simple to replace when required.**

*All you have to do is order a replacement from your supplier!*



## Bluelab Acid/Alkali Resistant Dosing Tube with Connectors

Replacement inlet/outlet tube - 13 foot / 4 meters.

**For use with Bluelab pH Controllers and stock solution.**

Dosing tube comes with connectors, so replacement is easy.

Bluelab Dosing Tube can be used with undiluted Bluelab pH Up or Bluelab pH Down.



## Bluelab pH Probe KCl Storage Solution

The perfect solution to store and hydrate your Bluelab pH products.

**Bluelab pH Probe KCl Storage Solution is designed to increase response time and maximize the life of Bluelab pH pens and pH probes.**

For best results, use the KCl solution to store the pH pen/probe after use and hydrate monthly. *Instructions are on the label of the bottle.*



### Use Bluelab pH Probe KCl Storage Solution with:



› Bluelab pH Pen

› Bluelab pH Probes

› Bluelab Soil pH Pen

› Bluelab Soil pH Probes



## Bluelab pH Controller limited product guarantee

Bluelab Corporation Limited guarantees the Bluelab pH Controller for a period of **2 years (24 months)** from the date of sale to the original purchaser. The Bluelab pH Probe is guaranteed for a period of 6 months.



### Standard Terms and Conditions of the Bluelab Limited Product Guarantee:

**How Long Does The Coverage Last?** 1) The product guarantee becomes effective from the date of purchase by the first purchaser. Coverage terminates if you sell or otherwise transfer the product; 2) The repair of your product under guarantee will not extend the period of the guarantee.

**How Do You Get Service?** 1) Products are to be returned to point of purchase; 2) Any parts replaced will become the property of Bluelab Corporation Limited ("Bluelab").

**What is covered?** Provided you supply proof of purchase via a store-printed receipt, we will repair or replace your product if your product is found, within the guarantee period, to be defective due to defective materials or workmanship existing at the time of purchase. If any part is no longer available or out of manufacture, Bluelab will replace it with a functionally-equivalent replacement part.

**What is not covered?** Bluelab shall not be liable for costs of repair or replacement of a product incurred as a result of: 1) Normal wear and tear; 2) Accidental damage, faults caused by negligent use or care, neglect, careless operation or handling of the product which is not in accordance with the Bluelab Instruction Manuals; 3) Use of parts not assembled or installed in accordance with the instructions of Bluelab; 4) Use of parts or accessories other than those produced or recommended by Bluelab; 5) External sources such as transit damage or weather; 6) Repairs or alterations carried out by parties other than Bluelab or its authorised agents; 7) Serial numbers defaced or missing.

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS GUARANTEE AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, GUARANTEES AND REMEDIES, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. ANY IMPLIED WARRANTIES THAT MAY BE IMPOSED BY LAW (INCLUDING, WITHOUT LIMITATION, MERCHANTABILITY) ARE LIMITED IN DURATION TO THE PERIOD OF THIS LIMITED GUARANTEE.

**How Does State Law Relate to This Warranty?** Some states do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to you. Additionally, some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This guarantee gives you specific legal rights, and you may also have other rights, which vary from state to state.

## Limitation of liability

Under no circumstances shall Bluelab Corporation Limited be liable for any claims, losses, costs and damages of any nature whatsoever (including any consequential loss) that result from the use of, or the inability to use, these instructions.