



SOLAR CYLINDER LANTERN

Instruction Manual
Model: GS-5



Replacement Solar LED Bulb and batteries are available at www.gamasonic.com or via our Toll free number: +1-800-835-4113

Maintenance

Clean the solar panels regularly with a damp towel to guarantee optimum performance. Do not use any type of solvent for cleaning and be careful not to put too much pressure on the solar panels while cleaning.

Troubleshooting

If your solar charged light does not come on at dusk despite observance of all the instructions, please try the following steps:

1. Make sure that the solar light is not being affected by any other light source.
2. Ensure the solar light is not positioned in the shade during the day.
3. Make sure the switch in the light is the ON position.
4. Check that the batteries are installed correctly.

Note: *The performance of the solar light will vary with the time of year. It will deliver more light when it has had a full day in the sun rather than a day in overcast weather.*

Wintertime Tips: *For optimal performance, be sure to remove any snow or debris accumulation from solar panel(s). A solar panel free of debris will charge the batteries much more efficiently.*



WARNING: *Please keep out of reach of children.*



Replacing the Batteries

After several years of use, the battery may need replacing.

1. Flip the lamp over and remove the screws from the bottom of the wall mount (A) (Fig. 6)
2. Take off the top to expose the inside.
3. Unplug the battery inside and replace it with the new battery using the clip.



This lamp takes a Li-Ion 3.2V/600 mAh battery pack.

WARNING: Do not dispose of Li-Ion battery in the regular trash, municipal waste stream or by fire as batteries may leak or explode. Do not open, short circuit, or mutilate batteries as injury may occur. Preserve our environment by recycling Li-Ion batteries or disposing of them in accordance with local, state and federal regulations. Do not mix old and new batteries.

4

Introduction

Thank you for your purchase. GAMA SONIC® solar-charged accent lighting eliminates the problems associated with most solar lighting available today. GAMA SONIC® solar-charged lights are brighter and last all night with a typical solar charge. Unique design, superior light output and numerous installation options confirm the outstanding value of our product.

GAMA SONIC® has been recognized as a worldwide leader in the lighting industry for over 20 years. The company also offers unique multi-purpose rechargeable products that range from fans with built in radios to emergency lighting products.

For technical assistance and more information call our Toll Free number: **1-800-835-4113** (only within the US)

Please read the instruction manual carefully to obtain the best results from your purchase.

Solar Light Location:

For optimum light duration throughout the night, it is very important to place your solar light in a spot where it will receive the maximum amount of direct sunlight throughout the day.

Note: The unit will operate optimally after 2 full days of charging in direct sun, and in the "on position"

WARNING: GAMA SONIC® Light bulbs are not to be used in other electrical sockets these are low-voltage light bulbs that are built and designed for our products only!

Replacing the Solar LED Bulb


The Solar LED Bulb is designed to last up to 10 years, however if it is not working, or if you want to use a different color temperature bulb,

you can replace it with a new GAMA SONIC Solar LED Bulb

1

What's Inside

Open your package and remove the contents. Check to make sure all pieces are present and accounted for.



2

Operation Instructions

- Flip the wall mount part of the lamp (Fig. 1) over and turn the cylinder (B) counterclockwise to release. Turn the operation switch (Fig. 2) to either the high or low position. The solar light will automatically operate at dusk. Reattach the cylinder (D) by twisting clockwise.

FIG. 1





FIG. 2



Installation Instructions

GS-5

1. Disassemble both the cylinder (D) and the lightbulb (B) by turning each counterclockwise.
2. Screw the wall mount (A) to a flat, vertical surface by drilling one hole and inserting the wall anchor. (Fig. 2).
3. Place the lamp on the wall with the holes aligning and twist the screw into the wall to hold in place.
4. Reattach the lightbulb (Fig. 4) and the cylinder (Fig. 5) and by twisting clockwise.

FIG. 3




FIG. 4



FIG. 5



3