

Multi Output Class 2 Installation Guide

! BEFORE YOU BEGIN



This transformer is to be installed in accordance with Article 450 of the National Electric Code. The transformer must be installed in a well-ventilated area free from explosive gases and vapors. Proper operation requires the free flow of air. As this transformer is hardwired, it should only be installed by a qualified electrician.

Precautions Before Installing

Check the label and ensure the transformer has the proper input voltage, output voltage and wattage for the job. Check the wire markings to ensure they match the wiring diagram on this instruction sheet.

Mounting

Select a suitable location capable of supporting the weight of the Transformer. Use the two keyholes in the transformer case. It is recommended that the transformer be mounted vertically with the wiring compartment pointing down.

Input Connections/Grounding

Remove the wiring compartment knockouts and install strain reliefs. With power turned off, route the input wires through a strain relief and connect one wire to black and one wire to white. For all wire connections use only UL listed wire nuts and connectors of suitable size and type. The transformer case **MUST** be grounded in accordance with the N.E.C. Connect the ground wire to the transformer green wire.

Output Connections

Bring the wires of each light fixture through the other open knockout and connect them to the terminal block output. Note that there are two, three or five terminal blocks according to the model in use. Connect the positive to the terminal marked (+)

positive and the negative wire to the terminal marked with (-) negative.

Caution!

Each individual terminal block is protected with auto circuit breaker therefore each terminal must be independent operated and may not be used in series or parallel to each other.

Boost-Tap (200W-300W Only)

The orange Boost-Tap wire is an optional 10% voltage boost, which can compensate for voltage drop between the driver and the fixture. If the fixture is receiving 10.5V or less we recommend substituting the black wire for the orange boost-tap wire.

If you need to quickly calculate the drop voltage

Magnigauge - The Ultimate Drop Voltage Calculator **Free App** suitable for Apple and Android Devices

[Click Here to Download](#)

Or go to www.magnigauge.magnitudeinc.com

