

# G50 Light String

Item: LELG506L15W

Rated Voltage: 120V, 60Hz, 0.06A, 7.2W

## IMPORTANT SAFETY INSTRUCTIONS:

**WHEN USING ELECTRICAL PRODUCTS, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED INCLUDING THE FOLLOWING:**

- (a) **READ AND FOLLOW ALL SAFETY INSTRUCTIONS.**
- (b) Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use.
- (c) When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
- (d) This seasonal use product is not intended for permanent installation or use.
- (e) Do not mount or place near gas or electric heaters, fireplaces, candles or other similar sources of heat.
- (f) Do not secure the wiring of the product with staples or nails, or place on sharp hooks or nails.
- (g) Do not let lamps rest on the supply cord or on any wire.
- (h) Unplug the product when leaving the house, when retiring for the night, or if left unattended.
- (i) This is an electric product-not a toy! To avoid risk of fire, burns, personal injury and electric shock, it should not be played with or placed where small children can reach it.
- (j) Do not use this product for other than its intended use.
- (k) Do not hang ornaments or other objects from cord, wire, or light string.
- (l) Do not close doors or windows on the product or extension cords as this may damage the wire insulation.
- (m) Do not cover the product with cloth, paper or any material not part of the product when in use.
- (n) This product employs overload protection (fuse). A blown fuse indicates overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Also unplug any additional strings or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded.
- (o) Read and follow all instructions that are on the product or provided with the product.
- (p) **SAVE THESE INSTRUCTIONS**

**WARNING: When using "outdoor" use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:**

## Use and Care Instructions:

- a) When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
- b) If the product is placed on a tree, the tree should be well secured and stable.
- c) Before using or reusing, inspect product carefully. Discard any products that have cut, damaged or frayed wire insulation or cords, cracks in the lamp holders or enclosures, loose connections, or exposed copper wire.
- d) When storing the product, carefully remove the product from wherever it is placed, including tree, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections, and wires.
- e) When not in use, store neatly in a cool, dry location protected from sunlight.

## USER SERVICE INSTRUCTION:

This plug contains an electrical fuse as a safety feature.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully.
4. Risk of fire. Replace fuse only with 3 Amp, 125 Volt fuse (provided with product).
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
6. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed
7. Discard product if the attachment plug is damaged.

**CAUTION:** To reduce the risk of fire and electric shock a) Do not install on trees having needles, leaves or branch coverings of metal or materials which look like metal, and b) Do not mount or support strings in a manner that can cut or damage wire insulation.

**CAUTION:** This filament light is rated 7.2 Watts (0.06 Amps), do not overload. Connect other filament lights or decorative outfits end-to-end up to a maximum of 216 Watts (1.8 Amps) total.

If connecting to a filament light that does not have a Wattage (W) rating (found on the tag within 6 inches of the plug) calculate the wattage as follows: Multiply the current (0.06 Amps) which is on the flag-type tag by 120.

## POWER RATE TABLE:

EMPEROR Item Number	Actual Lighted Length in Feet	Total Number of LEDs (Qty)	AMPS/Kit	Watts stated on the listing flag sticker (Watts/Kit)	Maximum combined Length stated on listing flag sticker (feet)	Operating Voltage & Frequency (Hz)	Max connected Wattage	Circuit Length (Feet)	Emperor UL Number	AMPS/ Kit	temperature
LELG506L15W	15Ft	90Pcs	0.06A	7.2W /kit	450Ft	120V, 60Hz	216 W	5Ft	E465986	0.06A	3000K+-300K